

S340


Kabelbaan
Telepherique
Seilbahn
Aerial Runway
Teleférico

Montagehandleiding Notice de montage Assembling manual Montageanleitung Instrucciones para el montaje


Leeftijd:
Age: 6-15
Age group:
Alter:
Edad:

EUROPLAY nv
Eegene 9
B-9200 DENDERMONDE
tel. 32.52.22 66 22
fax.32.52.22 67 22
www.europlay.eu


Dat.: 28/02/2012
Page: 1/11



VALHOOGTE / HAUTEUR DE CHUTE
FALL HEIGHT / FALLHÖHE / ALTURA DE CAÍDA
















VEILIGHEIDSAFSTAND / ESPACE DE CHUTE / SAFETY AREA /
SICHERHEITSABSTAND / ZONA DE SEGURIDAD






AFMETINGEN
DIMENSIONS
MASSE
DIMENSIONES
L : 20260
H: 3600
Br: 2210

Benodigdheden -- Liste des pièces -- Requisites -- Benötigtes -- Accesorios


4x 18,7 kg		KA354			
				Ø120 x 3540	
4x 21,2 kg		KA400			
				Ø120 x 4000	
2x		KA150			
				Ø100 x 1500	
2x		KA140			
				Ø160 x 1400	
6x		KA110			
				Ø100 x 1100	
4x		KA90			
				Ø120 x 900	
4x		KA80			
				Ø120 x 800	
2x 13,3 kg				2x 35 kg	
					
1x				1x	
					
				1x	
					
				2x	
					
12x		52x M12 4x M10		8x	
					
				M12	
		52x M12 12x M10		12x	
				M10	
				52x	
				M12	
				1x	
					
4x		M10x180		28x	
8x		M10x200			
24x		M12x140			
16x		M12x200			
4x		M12x220			
8x		M12x230			
					
				4,5 x 50	









1




2



DETAIL B
SCALE 2 : 25


M12 x 230




DETAIL A
SCALE 1 : 8

2x

3



4





5

P


KA400

M12 x 230

M12 x 200

DETAIL P
SCALE 1 : 15


6




7

Herhaal punt 2 tot en met 5 voor het 2de vertrekstation
Répétez points 2 à 5 pour la deuxième station de départ
wiederholen sie punkt 2 bis 5 für die 2e abfahrtsstation
Repeat points 2 till 5 for the second departure station
Repita el punto 2 hasta 5 para la segunda estación de salida


8




9




10




11




12




13




14




15




16




17



18



19



20

Bij droog weer moeten alle bouten en schroeven opnieuw aangespannen worden.
Par temps sec il faut resserrer régulièrement toute la visserie.
By dry and warm weather check the tightness of all bolts and screws.
Bei trockenem Wetter müssen alle Schrauben und Bolzen aufs neue angespannt werden.
Para el tiempo seco, se necesita cerrar o ajustar los tornillos y tuercas.