

S901

CARROUSEL
CARROUSEL
CARROUSEL
KARRUSSELL
CARROUSEL


Montagehandleiding Notice de montage Assembling manual Montageanleitung Instrucciones para el montaje

Leeftijd:
Age:
Age group:
Alter:
Edad:
5-12


EUROPLAY nv
Eegene 9
B-9200 DENDERMONDE
tel. 32.52.22 66 22
fax.32.52.22 67 22
www.europlay.eu

Dat.: 1/07/2013



Page: 1/3



VALHOOGTE / HAUTEUR DE CHUTE
FALL HEIGHT / FALLHÖHE / ALTURA DE CAÍDA


















VEILIGHEIDSAFSTAND / ESPACE DE CHUTE / SAFETY AREA /
SICHERHEITSAFSTAND / ZONA DE SEGURIDAD






AFMETINGEN
DIMENSIONS
MASSE
DIMENSIONES
L : 144 CM
H : 85 CM
Br: 144 CM

Benodigdheden Liste des pièces Requisites Benötigtes Accesorios

<p>1X</p>  <p>13 kg</p>	<p>1X</p>  <p>110 kg</p>	<table border="1"> <tr> <td data-bbox="1050 206 1173 571">4X</td> <td data-bbox="1173 206 1444 369">  </td> <td data-bbox="1444 206 1527 369">M14</td> </tr> <tr> <td data-bbox="1050 369 1173 571">4X</td> <td data-bbox="1173 369 1444 571">  </td> <td data-bbox="1444 369 1527 571">M14</td> </tr> <tr> <td data-bbox="1050 571 1173 761">4x</td> <td data-bbox="1173 571 1444 761">  </td> <td data-bbox="1444 571 1527 761">M14</td> </tr> </table>	4X		M14	4X		M14	4x		M14
4X		M14									
4X		M14									
4x		M14									




72h




3

A




B




C

4x M14

4x M14



C



DETAIL C
SCALE 1:7